


Minnesota Valley  
Antique Farm Power & Machinery Association



## Heritage Hill Tractor Pull

5152 20<sup>th</sup> Avenue SW, Montevideo, MN 56265

For questions or more information call --- Joe Schumacher 320-406-5423

---

**We are operating the 2024 pull with a different skid than previous years. If there are concerns about classes, rules, or other questions please contact us. We would like to accommodate anybody who would like to pull anything including: Trucks, semis, tractors, you name it. Classes can be added by request.**

---

# TRACTOR & TRUCK CLASSES

## Tractor Weight Classes (lbs)

- **Stock 4MPH:** 3500, 4000, 4500, 5000, 5500, 6000, 6500, 7000, 7500, 8000, 8500, 9500, 10,500, 11,500, 12,500, 15000+.
- **Improved 6MPH:** 3500, 4000, 4500, 5000, 5500, 6000, 6500, 7000, 7500, 8000, 8500, 9500, 10,500, 11,500, 12,500, 15000+. **NO TIRE RESTRICTIONS, CUT TIRES ALLOWED**
- **Open:** 3500, 4000, 4500, 5000, 5500, 6000, 6500, 7000, 7500, 8000, 8500, 9500, 10,500, 11,500, 12,500, 15000+. **NO TIRE RESTRICTIONS, CUT TIRES ALLOWED**

**\*ALL CLASSES HAVE A 100 LBS. OVERWEIGHT ALLOWANCE\***

## Truck Weight Classes (lbs)

- **Gas Pickup Trucks:** 5500, 6200
- **Diesel Pickup Trucks:** 8500, 9000
- **Semi:** Open

Classes can be added by request, call Joe to discuss. We will pull just about anything!

**\*Prizes will be awarded at the end of a class\***

# TRACTOR PULL RULES

## - Entry Fee

- An entry fee\* of \$20 for each hook is to be paid at the time of registration. If you decide to pull more than planned, more hooks can be added at the registration table for the same \$20 fee. All entries after 5pm on day of pull will be assessed a \$10 late fee.
- **EACH TRACTOR CAN HOOK NO MORE THAN 3 TIMES.** This rule is subject to change based on puller attendance, but to keep the pull moving smoothly, a hook limit has been implemented.
- \*Disclaimer: the entry fee is non-refundable EXCEPT if the pull is canceled for uncontrollable reasons (weather, track or pulling skid emergency, etc.).

## - Drawbar

Drawbar maximum height is to be 20" and a minimum of 18" from the center of the rear axle to the hook point of the drawbar. Drawbar must have a minimum hole size of 3/4" or a 3" opening able to receive a hook, not more than 2" forward of the rear of the drawbar. Drawbar must be stationary in all directions.

## - Tires

Radial tires are allowed. Cut tires are only allowed in 6mph **Improved** and **Open** classes.

- 3500-4500: 13.6x38, 14.9x28
- 5000-6500: 14.9x38, 15.5x38, 18.9x34
- 7000-7500: 16.9x38, 18.4x28, 18.4x38
- 6mph classes have no tire regulations.

## - Stock Class

Stock class tractors should appear stock with factory made block intake and carburetor, working governor, no side shields, 20% over on factory RPM's, 3000 RPM max.

## - Weights

No weights shall be placed more than 11' forward of the center of the rear axle of the tractor.

## - Hook-up and Un-hook

Tractors must be placed in neutral when hooking up and unhooking from the sled.

- **Speed Limit Horn Rules**  
Shall the speed limit horn on the pulling skid sound 3 TIMES, you will be automatically disqualified. Depending on skid we may run the 100' rule.
- **Judges**  
The track judges will have the final decision in all rules and regulations of the pull.
- **Entrant Qualification**  
Contestants enter at their own risk.
- **Termination of Pull**  
The pull is terminated when the forward motion of the tractor stops.
- **No Re-Pull**  
You will be given fair attempts to take off.
- **Equipment Required**  
Open tractors must have a kill switch that can hook to the pulling sled, 3000 RPM max.
- **Equipment Not Allowed**
  - **Stock Class**, no turbo chargers will be allowed, a working governor is mandatory, no cut tires will be allowed.
- **Age Requirement**  
Any person under the age of 18 must have parent or legal guardian present during registration and provide written consent for child to pull a tractor.
- **Safety**  
Pullers MUST drive at a safe speed both during and after a pull. No consumption of alcohol before or during the pull by pullers is allowed. Violators of these rules are subject to ejection from the pull.

