


Minnesota Valley



Antique Farm Power & Machinery Association

## Heritage Hill Tractor Pull

4 miles east of Montevideo, MN on Highway 7

For information call --- Nate Hoffmann 320-805-0282 or Grant Schmieg 605-291-9551

---

## TRACTOR PULL CLASSES

### Weight Classes (lbs)

- **Stock 1959 and older:** 3500, 4000, 4500, 5000, 5500, 6000, 6500, 7500, 8500, 9500. **MAX 4 MPH**
- **Open Class:** 4500, 5000, 5500, 6000, 6500, 7000, 7500, 8000, 8500, 9000, 9500.
- **Out of Field:** 7500, 8000, 8500, 9000, 9500, 10,000, 10500 **MAX 6 MPH**
- **V Class:** 6500, 7500, 8500, 9500, 10500 (V8 engines)
- **KING OF THE HILL:** Stock class tractors will be allowed 1 hook in this class. These hooks do not count toward your standing in original Stock class, or your 3 hook limit. 4500, 6500. **NO SPEED LIMIT**

**\*ALL CLASSES HAVE AN OVERWEIGHT ALLOWANCE OF 200 LBS.\***

**\*Payouts for each class will be determined by pull attendance\***

**Safety is everyone's obligation. Operators observed in unsafe practices may be asked to leave the show-site.**

# TRACTOR PULL RULES

## - Entry Fee

- An entry fee\* of \$20 for each hook is to be paid at the time of registration. If you decide to pull more than planned, more hooks can be added at the registration table for the same \$20 fee. All entries after 7pm on day of pull will be assessed a \$10 late fee.
- **EACH TRACTOR CAN HOOK NO MORE THAN 3 TIMES.** This rule is subject to change based on puller attendance, but to keep the pull moving smoothly, a hook limit has been implemented.
- \*Disclaimer: the entry fee is non-refundable EXCEPT if the pull is canceled for uncontrollable reasons (weather, track or pulling skid emergency, etc.).

## - Drawbar

Drawbar maximum height is to be 20" and a minimum of 18" from the center of the rear axle to the hook point of the drawbar. Drawbar must have a minimum hole size of 3/4" or a 3" opening able to receive a hook, not more than 2" forward of the rear of the drawbar.

## - Weights

No weights shall be placed more than 11' forward of the tractor.

## - Hook-up and Un-hook

Tractors must be placed in neutral when hooking up and unhooking from the sled.

## - Speed Limit Horn Rules

Shall the speed limit horn on the pulling skid sound **2 TIMES**, you will be automatically disqualified.

## - Judges

The track judges will final decision in all rules and regulations of the pull.

## - Entrant Qualification

Contestants enter at their own risk. A waiver must be signed before your hook.

## - Termination of Pull

The pull is terminated when the forward motion of the tractor stops.

- **Re-Pull**

Re-pull's may be granted if driver stops within 50' of the starting line. The first puller in each class has the option of taking a re-pull in third position but must tell the flagman before unhooking from the sled otherwise a re-pull may be denied.

- **Equipment Required**

Open class tractors must have a kill switch that can hook to the pulling sled

- **Equipment Not Allowed**

- **All classes**, Dual tires, fuel mixtures of any kind, fuel injection or gas under pressure unless factory equipped.
- **Stock Class**, no turbo chargers will be allowed, a working governor is mandatory, no shaved tires will be allowed.

- **Age Requirement**

Any person under the age of 18 must have parent or legal guardian present during registration and provide written consent for child to pull a tractor.

- **Safety**

- Pullers **MUST** drive at a safe speed both during and after a pull.
- **MAX** engine speed must not exceed rated engine RPM by more than 20%.
- **ANY** tractor that loses any parts on the track will be disqualified.

- **Conduct**

Consuming alcohol or being under the influence of alcohol will be deemed a safety violation and the participant may be denied participation in the event and asked to leave the tractor pull site.

**Safety is everyone's responsibility, any action or equipment deemed unsafe by the judge are grounds for disqualification. The decision of the judge or flag man is final and cannot be appealed.**

