


Minnesota Valley  
Antique Farm Power & Machinery Association



4 miles East of Montevideo, MN on HWY 7  
Heritage Hill  
MONTEVIDEO, MN 56265

+++++

**TRACTOR PULL RULES**

For information call --- Denny Kurtzbein 320-841-1219- Gerald Kleene 320-894-9149

+++++

**Classes**

**Stock**, 1959 and older, 3500, 4500, 5500, 6500, 7500, 8500, 9500, & Above **4 MPH**

**Open Class**, 4500, 5500, 6500, 7500, 8500, 9500

**Out of Field**, 7500, 8500, 9500, 10500 **6 MPH**

**V Class**, 6500, 7500, 8500, 9500, 10500 (V8 engines)

**Safety is everyone's obligation. Operators observed in unsafe practices may be asked to leave the show-site.**

**Entry Fee**

A non refundable entry Fee of \$20.00 for each pull us to be paid at time of registration

**Drawbar**

Drawbar maximum height is to be 20" and a minimum of 18" from the center of the rear axle to the hook point of the drawbar. Drawbar must have a minimum hole size of 3/4" or a 3" opening able to receive a hook, not more than 2" forward of the rear of the drawbar.

**Weights**

No weights shall be placed more than 24" forward of the tractor.

**Hook-UP & Un Hook**

Tractors must be placed in neutral when hooking up and unhooking from the sled.

### **Termination of pull**

The pull is terminated when the forward motion of the tractor stops.

### **Re-Pull**

Re-pull's may be granted if driver stops within 50' of the starting line. The first puller in each class has the option of taking a re-pull in third position, but must tell the flagman before unhooking from the sled otherwise a re-pull may be denied.

### **Conduct,**

Consuming alcohol or being under the influence of alcohol will be deemed a safety violation and the participant may be denied participation in the event and asked to leave the tractor pull site. The decision of the judge will be final in all cases.

### **Equipment not allowed**

**All classes,** Duals, Shaved tires on **stock**, no fuel mixtures in any class

**Stock Class,** no turbo chargers will be allowed, a working governor is mandatory.

### **Entrant qualification**

Contestants enter at their own risk. No contestants under 16 years of age will be allowed to participate

### **Safety,**

Pullers must drive at a safe speed both during and after a pull

Maximum engine speed must not exceed rated RPM by more than 20%

Any tractor that loses any parts on the track will be disqualified.

**Safety is everyone's responsibility, any action or equipment deemed unsafe by the judge are grounds**

**for disqualification. The decision of the judge or  
flagman is final and cannot be appealed.**

